


**LAB: Enable the Telemetry configuration on Cisco Router, Telegraf will receive the stats and store in Influx DB , Grafana will be used to display the stats.**

**Step1 :** Build the topology as per below, DHCP server will assign the IP address on Router



```
*Jan 14 05:21:33.241: %SYS-5-CONFIG_1: Configured from console by consoleip int
b
Interface          IP-Address      OK? Method Status        Protocol
GigabitEthernet1    172.20.0.79     YES DHCP    up            up
GigabitEthernet2    unassigned      YES unset    down          down
GigabitEthernet3    unassigned      YES unset    down          down
GigabitEthernet4    unassigned      YES unset    down          down
```

**Step 2:** Configure the router for Yang-Management process

user admin privilege 15 secret cisco123

aaa new-model

aaa authentication login default local

aaa authorization exec default local

Netconf-yang

Show platform software yang-management process

```
Router#show platform software yang-management process
confd          : Running
nedd           : Running
syncfd         : Running
ncsshd         : Running
dmiauthd       : Running
nginx          : Running
ndbmand        : Running
pubd           : Running
```

**Step 3:** Configure the Telemetry on router for CPU, Memory, and Interface

Login to below URL:

<https://github.com/jeremycohoe/cisco-ios-xe-mdt/blob/master/cat9k-174-device-health-dashboa>

Configure the Telemetry for IETF 3305, 3307, 3310, 3313, 3314 as per the commands described on above URL

**Source IP address:** Ip address of router (check show ip interface br)

**Receiver IP:** 172.20.0.11 (Telegraf IP address)

Post configuration, check the status of Telemetry on router as per below


```
Router#show telemetry ietf subscription all
Telemetry subscription brief
```

| ID   | Type       | State | Filter type |
|------|------------|-------|-------------|
| 3305 | Configured | Valid | xpath       |
| 3307 | Configured | Valid | xpath       |
| 3310 | Configured | Valid | xpath       |
| 3313 | Configured | Valid | xpath       |
| 3314 | Configured | Valid | xpath       |

```
Router#show telemetry internal connection
Telemetry connection
```

| Peer Address | Port  | URF | Source Address | Transport | State  | Profile |
|--------------|-------|-----|----------------|-----------|--------|---------|
| 172.20.0.11  | 57500 | 0   | 172.20.0.79    | grpc-tcp  | Active |         |


Go to shell prompt



### Check the telegraf and influxdb container configuration




Docker-compose up -d




### Step 5: Login to Grafana:

172.20.0.11:3000 (admin/mypass)



### Import the InfluxDB database

Connection/ data source



|                   |          |
|-------------------|----------|
| Database          | mdt_grpc |
| User              |          |
| Password          | Password |
| HTTP Method       | GET      |
| Min time interval | 5s       |
| Max series        | 1000     |

## Import the Dashboard:

<https://grafana.com/grafana/dashboards/13462-device-health-monitoring/>

Copy to clipboard

The screenshot shows the Grafana Labs website. The main heading is "Enable gRPC subscription configuration on IOS XE". Below it, a note says "More details will be added once validated ;)". A code block contains the following text:

```
! NETCONF-yang is required for gRPC Dial-Out telemetry:
netconf-yang

! Remove any previous MDT configuration:
no telemetry ietf subscription 3301
```

To the right of the code block is a "Copy" button. On the right side of the page, there is a section titled "Import the dashboard template:" with two buttons: "Copy ID to clipboard" and "Download JSON". Below these buttons is a link that says "Docs: Importing dashboards".

Go to Grafana: Dashboard/import

The screenshot shows the "Dashboards / Import dashboard" page in Grafana. The page title is "Dashboards / Import dashboard" and the subtitle is "Import dashboard from file or Grafana.com". The main heading is "Importing dashboard from Grafana.com". Below this, there is a table with the following information:

|              |                     |
|--------------|---------------------|
| Published by | jeremycohoe         |
| Updated on   | 2021-04-15 03:26:47 |

Below the table is the "Options" section. It contains the following fields:

- Name:** Device Health Monitoring
- Folder:** General (dropdown menu)
- Unique identifier (UID):** 5dlfYeR0Gk (with a "Change uid" button)
- Influx\_mdt\_grpc:** InfluxDB (dropdown menu)

At the bottom of the form are two buttons: "Import" and "Cancel".

Check the Grafana Dashboard: CPU, Memory, and interface stats to be updated.

